



ASSEMBLY INSTRUCTIONS

1. Carefully unpack and identify all parts referring to illustration for parts identification.
2. Turn the power to the installation point OFF.
3. While threading wire through, assemble the rods (5) together using the nipples (4). Attach the bottom end of the rods (5) into the nipple (6) until hand tight.
4. Secure the loop (3) onto the top of the rods (5).
5. Install the bulb (not included) into the socket (8).
6. Install the glass (10) over the bulb and onto the glass holder (7).
7. Use quick link to connect loop (3) onto the canopy (1) and twist the locking mechanism to secure.
8. Twist the cylinder nut (2) onto the canopy (1).
9. Refer to the additional installation instructions included with the product of wiring and installation.
10. Restore power to the installation point and retain this sheet for future reference.